

Procedure for replacement of door bell battery

1.) Take down the door bell. (Fig. 1)



Fig. 1

2.) Open the battery compartment lid. (Fig. 2)




Fig. 2

3.) Insert 3 nos. of battery (size AA) and cover the battery compartment lid. (Fig. 3)




Fig. 3

4.) Select the bell sound at the side of bell. (Fig. 4)



Fig. 4

5.) Open and remove the door bell button. (Fig. 5 & 6)



Fig. 5



Fig. 6

6.) Unscrew the cover. (Fig. 7)



Fig. 7

7.) Insert the 9V battery and assembling all parts. (Fig. 8)




Fig. 8