## Laundry – Smartcard Payment System

Place clothes inside the Washer / Dryer machine. Close machine door. \* Do **NOT** load more than 5.2kg of clothes into the machine For Washer: Add **foamless** detergent / softener in machine (Do **NOT** use foam-detergent) For Dryer: Select drying programme (drying time & temperature) by rotating the control knob 2 Go to the payment kiosk 3 Select [Laundry Service] 香港理工大學, THE HONG KONG POLYTECHNIC UNIVERSITY THE HONG KONG POLYTECHNIC UNIVERSITY 香港理工大學 歡迎使用宿舍繳費站 Welcome to the Hall Payment Kiosk 請選擇 Please choose: 洗衣服務 房間冷氣 **Laundry Service** Air-conditioning in Room 杏悶本站繳費記錄 Check local payment transaction Chinetek Group Co. Ltd http://www.chinetekgroup.com \* Ver. 20/10/23/003





## Air-Conditioning - Smartcard Payment System









